

Contents

Acknowledgments	14
Introduction	15
Chapter 1: Preliminary Setup	18
Setting Up the Camera	18
Charging and Inserting the Battery	18
Inserting the Memory Card	20
Setting the Language, Date, and Time	25
Chapter 2: Basic Operations	27
Taking Pictures	27
Introduction to Main Controls	27
Top of Camera	28
Back of Camera	28
Front of Camera	29
Right Side of Camera	29
Fully Automatic: AUTO Mode	30
Basic Variations from Fully Automatic	32
Focus	33
Autofocus	33
Manual Focus	36
Exposure	37
Exposure Compensation	37
Flash	40
Movie Recording	42
Viewing Pictures	44
Review While in Recording Mode	44
Reviewing Images in Playback Mode	44
Playing Movies	44
Chapter 3: The Shooting Modes	47
AUTO Mode	47
Program Mode	49
Aperture Priority Mode	50
Shutter Priority Mode	55
Manual Exposure Mode	58
Scene Mode	61
Movie Digest	63
Portrait	64

Landscape	64
Kids & Pets	64
Smart Shutter	65
High-Speed Burst HQ	66
Handheld Night Scene	67
Beach	68
Underwater	68
Foliage	68
Snow	69
Fireworks	69
Stitch Assist	69
Comparison of Shooting Mode Appearances	72
Creative Filters Mode	73
HDR	73
Nostalgic	76
Fish-eye Effect	78
Miniature Effect	78
Toy Camera Effect	80
Monochrome	80
Super Vivid	81
Poster Effect	82
Color Accent	82
Color Swap	83
Custom Mode	85
Chapter 4: Function menu, Shooting Menu, and My Menu	87
The Function Menu	87
i-Contrast	88
ISO	90
White Balance	93
My Colors	96
Vivid	97
Neutral	99
Sepia	99
B/W	99
Positive Film	99
Lighter Skin Tone	99
Darker Skin Tone	100
Vivid Blue	100

Vivid Green	100
Vivid Red	100
Custom Color	100
Bracketing	101
Exposure bracketing	101
Focus bracketing	103
Continuous Shooting	104
Self-timer	107
AF Frame	108
Face AiAF	108
Tracking AF	109
FlexiZone	110
Metering Method	111
ND Filter	113
Aspect Ratio	114
Image Type	117
Image Size and Quality	120
Movie Resolution	121
The Shooting Menu	122
AF Frame Size	124
Digital Zoom	124
AF-Point Zoom	126
Servo AF	127
AF-Assist Beam	127
MF-Point Zoom	128
Safety MF	128
Flash Settings	129
Flash Mode	129
Flash Exposure Compensation and Flash Output	131
Shutter Sync.	131
Red-Eye Correction	132
Red-Eye Lamp	133
Safety FE	133
Hg Lamp Correction	133
ISO Auto Settings	134
High ISO NR	135
Spot AE Point	135
Safety Shift	136

Wind Filter	136
Review	136
Review Info	137
Blink Detection	138
Custom Display	138
IS Settings	139
Date Stamp	140
Set Control Ring Function	141
Set Ring Function Button	141
Ring Function	142
Face Select	142
i-Contrast	142
ISO Speed	143
White Balance	143
Custom White Balance	143
My Colors	144
Drive Mode	144
Self-timer	144
AF Frame	144
Light Metering	144
ND Filter	144
Aspect Ratio	145
RAW or JPEG	145
Servo AF	145
Red-Eye Correction	145
Powered IS	146
AF Lock	146
AEL	146
Digital Tele-converter	147
Display Off	147
Save Settings	148
My Menu	149
Chapter 5: Other Controls	152
Mode Dial	152
Shutter Release Button	153
Zoom Lever	153
Power Button	154
AF Assist/Self-timer Lamp	154

Control Ring	155
Ring Function Button	155
Playback Button	158
Menu Button	158
Control Dial and Its Buttons	160
Control Dial	160
Func./Set Button	162
Direction Buttons	163
Top Button	163
Right Button: Flash Settings	166
Bottom Button: Display	166
Left Button: Focus Options	167
Indicator	167
Chapter 6: Playback and Printing	169
Normal Playback	169
Index View and Enlarging Images	170
Scroll Display	172
Different Playback Screens	172
Filtered Playback and Jumping	176
The Playback Menu	179
Movie Digest Playback	179
Slideshow	181
Erase	182
Protect	184
Rotate	185
Favorites	185
My Category	186
People	186
Scenery	187
Events	187
i-Contrast	189
Red-Eye Correction	190
Trimming	191
Resize	192
My Colors	192
Scroll Display	194
Group Images	194
Auto Rotate	195

Resume	195
Transition	195
Printing Images	196
Printing Directly from the Camera	196
The Print Menu	197
Chapter 7: Setup Menu	199
Mute	199
Volume	200
Sound Options	200
Hints & Tips	201
LCD Brightness	201
Start-up Image	202
Format	202
File Numbering	203
Create Folder	204
Lens Retract	204
Power Saving	205
Time Zone	206
Date/Time	207
Time Update	207
GPS Settings	207
Distance Units	209
Video System	210
CTRL via HDMI	210
Eye-Fi Settings	210
Language	211
Reset All	212
Chapter 8: Motion Pictures	213
Movie-making Overview	213
Recording in Non-Movie Shooting Modes	214
Shooting in Movie Mode	217
Function Menu	218
Movie Mode	218
White Balance	220
My Colors	220
Self-timer	220
AF Frame	221
ND Filter	221

Image Size	221
Movie Resolution	222
Shooting menu	222
AF Frame Size	223
Digital Zoom	223
AF-Assist beam	224
Safety MF	224
Wind Filter	224
Custom Display	224
IS Settings	225
Set Ring Function button	225
Other Settings and Controls	225
Exposure Compensation and Exposure Lock	226
Control ring	227
Movie Playback	228
Chapter 9: Other Topics	231
Macro (Closeup) Shooting	231
Using RAW Quality	233
Using Flash	235
Other Flash Settings	238
Infrared Photography	240
Street Photography	242
Making 3D Images	245
Connecting to a Television Set	246
APPENDIX A: Accessories	249
Cases	249
Batteries	250
AC Adapter	251
Add-on Filters and Lenses	252
Flash	254
APPENDIX B: Quick Tips	258
APPENDIX C: Resources for Further Information	264
Index	268