

Contents

INTRODUCTION	1
CHAPTER 1: PRELIMINARY SETUP	3
Charging and Inserting the Battery	3
Inserting the Memory Card	4
Introduction to Main Controls	4
Top of Camera	5
Back of Camera	5
Front of Camera	6
Right Side of Camera	6
Left Side of Camera	6
Bottom of Camera	6
Setting the Date, Time, and Language	7
CHAPTER 2: BASIC OPERATIONS	8
Taking Pictures in Intelligent Auto Mode	8
Motion Picture Recording	9
Basic Playback Procedures	10
Playing Movies	11
CHAPTER 3: THE RECORDING MODES	12
Choosing a Recording Mode	12
Preliminary Steps Before Shooting Pictures	13
Intelligent Auto Mode	13
Options on Special Menu for Intelligent Auto Mode	14
Options on Recording Menu	15
Intelligent Auto Plus Mode	15
Program Mode	17
Aperture Priority Mode	19
Shutter Priority Mode	20
Manual Exposure Mode	22
CHAPTER 4: THE RECORDING MENU AND THE QUICK MENU	24
The Recording Menu	24
Picture Size	26
Extended Optical Zoom	27
Quality	27
AFS/AFF/AFC	29
Photo Style	30
Filter Settings	32
Color Space	40
Metering Mode	40
Highlight Shadow	41
Intelligent Dynamic	42
Intelligent Resolution	42
Flash	43

- Firing Mode 43
- Flash Mode. 44
- Flash Synchro 45
- Flash Adjustment 46
- Auto Exposure Compensation 46
- Manual Flash Adjustment 47
- Wireless. 47
- Wireless Channel. 47
- Communication Light 47
- Wireless Setup 47
- Red-eye Removal 49
- ISO Auto Upper Limit (Photo) 49
- Minimum Shutter Speed 49
- Long Shutter Noise Reduction 49
- Diffraction Compensation 49
- Stabilizer 50
- Intelligent Zoom 50
- Digital Zoom 51
- Burst Rate 51
- 4K Photo. 51
- Self-timer 51
- Time Lapse Shot 51
- Stop Motion Animation 52
- Panorama Settings 53
- Silent Mode 54
- Shutter Type 54
- Bracket 54
 - Exposure Bracket 55
 - Aperture Bracket. 56
 - Focus Bracket 57
 - White Balance Bracket. 57
 - Aspect Bracket. 58
- HDR 58
- Multiple Exposure 60
- Quick Menu 61

CHAPTER 5: PHYSICAL CONTROLS

- Aspect Ratio Switch 63
- Aperture Ring 64
- Control Ring 64
 - Step Zoom 65
- Focus Switch. 65
- Shutter Button 66
- Zoom Lever 66
- On/Off Switch 66
- Shutter Speed Dial. 67
- Exposure Compensation Dial 67
- iA (Intelligent Auto) Button 68
- Fn1 Button 68
- Viewfinder, Eye Sensor, and Diopter Adjustment Dial 68
- Control Dial and its Buttons. 69
 - Control Dial 69
 - Direction Buttons 69
 - Up Button: ISO 69
 - Right Button: White Balance. 71
 - Left Button: Autofocus Mode/MF Assist 73

Use of Left Button in Autofocus Mode	73
Face/Eye Detection	73
AF Tracking	74
49-Area	74
Custom Multi	75
1-Area	76
Pinpoint	77
Moving the Focus Frame or Focus Area	78
Use of Left Button in Manual Focus Mode	78
Down Button: Drive Mode	78
Burst Shooting	79
4K Photo	80
4K Burst	81
4K Burst S/S	81
4K Pre-burst	81
Extracting a 4K Photo Still Image	81
Post Focus	83
Focus Stacking	85
Self-timer	86
Panorama	87
Center Button: Menu/Set	88
Movie Button	89
AF/AE Lock Button	89
Playback Button	89
Display Button	89
Charging/Wireless Connection Lamp	90
Function Buttons	90
Fn1/4K Photo Button	90
Fn2/Q.Menu Button	91
Fn3/Delete/Cancel Button	91
Fn4/Post Focus Button	91
Fn5/LVF Button	92
Assigning Functions to Function Buttons	92
Preview	93
Focus Area Set	94
Touch AE	94
Operation Lock	95
AF Mode/MF	95
Record/Playback Switch	95
Restore to Default	95
Assigning Options to Function Buttons for Playback Mode	95
LCD Monitor	96
Using the Touch Screen	96
AF Assist/Self-timer Lamp	98

CHAPTER 6: PLAYBACK

99

Index View and Enlarging Images	99
The Playback Menu	100
Slide Show	100
[Play] All	100
[Play] Picture Only/Video Only	101
Playback Mode	101
Protect	101
Rating	102
Title Edit	102
Face Recognition Edit	103

Raw Processing	103
4K Photo Bulk Saving	105
Light Composition	105
Sequence Composition	106
Clear Retouch	107
Text Stamp	108
Resize	108
Cropping	109
Rotate	109
Video Divide	110
Time Lapse Video	110
Stop Motion Video	111
Rotate Display	111
Picture Sort	111
Delete Confirmation	111
Printing Directly from the Camera	112

CHAPTER 7: THE CUSTOM MENU AND THE SETUP MENU 113

The Custom Menu	113
ISO Increments	113
Extended ISO	114
Exposure Compensation Reset	114
AF/AE Lock	114
AF/AE Lock Hold	115
Shutter AF	115
Half Press Release	115
Quick AF	115
Eye Sensor AF	116
Pinpoint AF Setting	116
Pinpoint AF Time	116
Pinpoint AF Display	116
AF Assist Lamp	117
Direct Focus Area	117
Focus/Release Priority	117
Focus Switching for Vertical/Horizontal	118
Loop Movement Focus Frame	118
AF Area Display	118
AF+MF	119
Manual Focus (MF) Assist	119
MF Assist Display	119
Function Button Set	120
Quick Menu (Q.Menu)	121
iA Button Switch	122
Control Ring	122
Operation Lock Setting	122
Video Button	123
Touch Settings	123
Touch Screen	123
Touch Tab	124
Touch AF	124
Touch Pad AF	124
Dial Guide	124
Zoom Lever	125
Auto Review	125
Monochrome Live View	126
Constant Preview	126

Live View Boost	126
Peaking	126
Histogram	127
Guide Line	128
Center Marker	129
Highlight	129
Zebra Pattern	129
Exposure Meter	130
MF Guide	130
LVF/Monitor Display Settings	131
LVF Display Setting	131
Monitor Display Setting	131
Monitor Information Display	131
Recording Area	132
Remaining Display	132
Lens Position Resume	132
Lens Retraction	132
Self Timer Auto Off	132
Face Recognition	133
Profile Setup	134
The Setup Menu	134
Online Manual	134
Utilize Custom Set Feature/Custom Set Memory	134
Clock Set	136
World Time	136
Travel Date	136
Wi-Fi	137
Bluetooth	137
Wireless Connection Lamp	137
Beep	137
Economy	137
Sleep Mode	137
Sleep Mode (Wi-Fi)	137
Auto LVF/Monitor Off	138
Monitor Display Speed	138
LVF Display Speed	138
Monitor Display/Viewfinder	138
Monitor Luminance	138
m/ft	139
Eye Sensor	139
USB Mode	139
TV Connection	139
Language	140
Version Display	140
Folder/File Settings	140
Select Folder	140
Create a New Folder	141
File Name Setting	141
Number Reset	141
Reset	141
Reset Network Settings	142
Level Gauge Adjustment	142
Demo Mode	142
Format	142
My Menu	142

CHAPTER 8: MOTION PICTURES 144

Basics of LX100 II Videography	144
Quick Start for Motion Picture Recording	144
General Settings for Motion Picture Recording	145
Exposure	145
Focus	146
Other Settings	147
The Motion Picture Menu	147
Recording Format	147
Recording Quality	148
AFS/AFF/AFC.	149
Continuous AF.	149
Photo Style.	149
Filter Settings	149
Metering Mode	149
Highlight Shadow	149
Intelligent Dynamic	150
Intelligent Resolution	150
ISO Auto Upper Limit (Video)	150
Diffraction Compensation.	150
Stabilizer	150
Intelligent Zoom.	150
Digital Zoom.	150
Picture Mode in Recording	150
Sound Recording Level Display	151
Sound Recording Level Adjustment	151
Wind Noise Canceller	151
Using External Microphones	151
Physical Controls	152
Using the Touch Screen During Video Recording	154
Silent Operation	154
Recommendations for Recording Video	155
Motion Picture Playback and Editing	155
Editing with a Computer	156

CHAPTER 9: WI-FI AND OTHER TOPICS 157

Using Wi-Fi and Bluetooth Features.	157
Controlling the Camera with a Smartphone or Tablet	159
Sending Images and Videos to a Smartphone or Tablet	160
Adding Location Data to Images.	162
Photo Collage.	163
Turning the Camera On or Off Using Bluetooth.	163
Controlling the Camera’s Shutter Button Using a Bluetooth Connection Only	164
Uploading Images by Wi-Fi to Social Networks	164
Connecting to a Computer to Transfer Images Wirelessly	165
Sending Images to Other Devices	166
Viewing Images Wirelessly on TV.	166
Other Menu Options for Wi-Fi and Bluetooth	166
Wi-Fi Function.	167
Wi-Fi Setup	167
Priority of Remote Device	167
Wi-Fi Password	167
Lumix Club.	168
PC Connection.	168
Device Name.	168

- Wi-Fi Function Lock 168
- Network Address. 168
- Approved Regulations. 168
- Bluetooth 168
 - Bluetooth. 168
 - Remote Wakeup 168
 - Returning from Sleep Mode. 168
 - Auto Transfer. 169
 - Location Logging 169
 - Auto Clock Set 169
 - Wi-Fi Network Settings 169
- Wireless Connection Lamp. 169
- Macro (Closeup) Shooting. 170
- Infrared Photography 170
- Digiscoping and Astrophotography 171
- Street Photography 172
- Portraits 173

APPENDIX A: ACCESSORIES 174

- Cases 174
- Batteries and Chargers 175
 - AC Adapter. 176
- Viewfinders. 176
- Add-on Filters and Lenses. 177
- External Flash Units 177
- Automatic Lens Cap 179
- External Microphones. 179

APPENDIX B: QUICK TIPS 180

APPENDIX C: RESOURCES FOR FURTHER INFORMATION 182

- Photography Books 182
- Websites 182
 - Digital Photography Review 182
 - Official Panasonic and Related Sites 182
- Reviews of the LX100 II 183

Index 184